

URANIUM TEST SAMPLING INSTRUCTIONS

STOP PLEASE READ ALL INSTRUCTIONS COMPLETELY BEFORE COLLECTING YOUR WATER SAMPLE **STOP**

One test kit represents one sampling location. If you require testing on multiple locations you will need to purchase multiple test kits.

1. Run the cold water for approximately 3-5 minutes, then adjust the flow to a thin stream to avoid splashing or overfilling.
2. Fill the bottle to the neck, cap securely.
3. Complete the enclosed lab form, **making sure to indicate the collection date and time you sampled**, type of water (treated/untreated) and sample identification which identifies where you collected your sample (i.e., kitchen sink, well head, etc.). Retain a copy of the lab form for your records and return the completed form to the shipping container.
4. Mail your sample to the testing location below. The sample does not require overnight shipping.

Testing Location: **National Testing Laboratories, Ltd.
556 South Mansfield Street
Ypsilanti, MI 48197**

5. PLEASE NOTE: Testing typically takes approximately 5-7 business days from receipt of samples. Results will be emailed upon completion.

NOTE: The lab reserves the right to reject water samples that appear to be excessively contaminated as they may cause potential damage to laboratory equipment.

If you have any questions regarding this Uranium Test or any other services we provide, please contact a Technical Service Representative at National Testing Laboratories at 1-800-458-3330 for assistance.

Thank you for choosing National Testing Laboratories, Ltd., for your water testing services!